


DB1 - B760



Please clarify Ref. No. and
Parts No. as well as parts name
When you place an order.


INDEX

Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark
100008-0 03	A- 5		100265-0-14	B-11		100338-0-01	C-63		102630-0-01	B-23	
100013-0-02	C-10		100266-0-01	A-43		100339-0-01	C-57		102632-0-01	B-13	
100013-0-03	B-36		100268-0-01	A-39		100343-0-01	B-64		102921-0-02	C-24	
///	C-12		100269-0-01	A-40		100351-0-01	B-71		103013-0-01	C- 4	
///	C-22		100271-0-01	B-16		100356-0-01	B-56		103555-0-00	B-71	
100016-0-01	B-15		100279-0-01	C- 1		///	B-70		103557-0-01	B-55	
100016-0-03	B-26		100287-0-04	A- 17		100367-0-01	B-77		103558-0-00	B-53	
///	B-31		///	C- 6		100368-0-02	B-76		103738-0-01	B-45	
///	B-44		100288-0-01	C-11		100369-0-01	B-79		103796-0-01	B-46	
///	B-54		100290-0-01	C-16		100385-0-01	A-11		103797-0-01	B-62	
///	B-58		100291-0-01	C- 9		100388-0-01	A-10		103950-0-02	A-29	
100032-0-01	A-42		100293-0-01	C-20		100388-0-04	A-27		103980-0-03	A-25	
100035-0-01	A- 41		100294-0-01	C-15		100389-0-01	A-26		104274-0-00	B-34	
100036-0-03	C-64		100295-0-01	C-23		100390-0-01	A-16 B-11		104376-0-00	B-14	
100062-0-04	B-40		100297-0-01	C-21		100391-0-01	A-16		104464-0-00	B-18	
100075-0-03	C- 51		100298-0-01	C-26		100392-0-01	A-21		104478-0-01	B-43	
///	C-61		100299-0-01	C-25		100393-0-01	A-19		104680-0-00	B-83	
100078-0-03	C-60		100300-0-01	C-28		///	A-22		///	B-85	
100080-0-03	C-13		100304-0-01	C-31		///	B- 9		///	C-40	
///	C-56		100305-0-01	C-33		100395-0-01	A-18		106121-0-01	B-12-16	
100086-0-03	C-54		100308-0-03	C-32		100397-0-01	A-31		///	20-21-22	
100119-0-03	A- 9		100307-0-00	B-37		100398-0-01	A-34		106424-0-04	B-87	
100134-0-01	A-36		100309-0-01	B-86		100399-0-01	A-33		106440-0-00	B-89	
100136-0-01	A-38		100310-0-01	B-82		100400-0-00	A-32		106442-0-01	B-88	
100137-0-01	B-25		///	B-84		100401-0-01	A-37		107428-0-01	B-80	
100235-0-00	A- 1		///	C-38		100402-0-02	A-30		108520-0-01	A-14	
///	A- 2		100311-0-00	C-39		100404-0-00	C-17		109206-0-01	B- 5	
///	A- 3		100312-0-01	C-41		100405-0-01	C-19		109801-0-01	C- 8	
///	A- 8		100313-0-01	C-35		100539-0-02	B-68		110161-0-03	C-27	
///	A-13		100316-0-01	C-47		///	B-72		110319-0-00	B-47	
100241-0-01	A-23		100320-0-01	A-12		100591-0-01	A- 7		110320-0-00	B-63	
100242-0-04	A-24		100320-0-02	C-50		100592-0-01	A- 6		110340-0-01	C- 5	
100248-0-01	B-29		100320-0-01	C-48		100597-0-00	B-32		110605-0-01	B-42	
100251-0-01	B-19		100322-0-01	C-46		100598-0-01	B-33		111274-0-01	B-75	
///	B-35		100324-0-03	C-53		100600-0-01	B-21		112190-0-01	B-10	
///	B-38		100326-0-03	C-45		100628-0-01	B-49		113280-0-01	C- 7	
///	B-51		100327-0-01	C-43		100630-0-00	B-48		113353-0-01	C-44	
///	B-61		100328-0-01	C-42		100633-0-01	B-52		113547-0-01	C-18	
///	B-66		100330-0-03	C-55		100634-0-00	B-59		114931-0-01	A-28	
100252-0-01	B-20		100331-0-02	C-52		100637-0-00	B-73		115812-0-02	B- 1	
100253-0-01	B-22		///	C-62		100638-0-00	B-67		116005-0-01	A-20	
100258-0-01	B- 4		100332-0-01	C-58		101706-0-01	B-57		116231-0-01	A-47	
100259-0-01	B- 3		100333-0-01	C-59		///	B-69		116951-0101	B- 7	
100260-0-01	B- 2		100335-0-01	B-81		102575-0-01	A-44		116998-0-01	B-39	
///	B- 6		///	B-85		///	A-44		117001-0-01	B-65	

I N D E X

Parts. No.	Ref. No.	Remark	Parts. No.	Ref. No.	Remark	Parts. No.	Ref. No.	Remark	Parts. No.	Ref. No.	Remark
117132-0-01	B-78										
117178-0-01	C-14										
117797-0-01	B-50										
117799-0-01	B-60										
117817-0-01	C-67										
117880-0-01	C-3										
117924-0-01	C-30										
118289-0-01	A-39~11										
118521-0-01	B-8										
118550-0-00	C-29										
140094-0-01	B-12										
140890-0-01	A-45										
141098-0-01	C-37										
141099-0-01	B-2										
142097-0-00	B-17										
142101-0-01	B-30										
142102-0-00	B-27										
143258-0-01	A-46										
180017-0-01	B-7.8										
180145-0-01	B-60.61. 65.66										
180192-0-01	B-37.87										
180195-0-01	A-30~38										
182060-0-01	B-3~5										

D760-2




PARTS LIST FOR DBI-B760

B760-3


Item No.	Name of Parts	Qty	Parts-No.	Assembly No.	Ref No.	Name of Parts	Qty	Parts-No.	Assembly No.
A-1	Oil Pipe for B-14, B-21	2 pcs.	100235-0-00						
A-2	Oil Pipe for B-20	1 pc.	100235-0-00						
A-3	Oil Pipe for B-16	1 pc.	100235-0-00						
A-5	Set Screw for Rear Cover	1 pc.	100008-0-03						
A-6	Rear Cover	1 pc.	100592-0-01						
A-7	Oil Pipe & Supporter	1 pc.	100591-0-01						
A-8	Oil Pipe for B-32	1 pc.	100235-0-00						
A-9	Felt for A-10	1 pc.	100119-0-03						
A-10	Spool Pin	2 pcs.	100386-0-01						
A-11	Spool Pin Base	1 pc.	100385-0-01						
A-12	Set Screw for A-11	2 pcs.	100320-0-01						
A-13	Oil Pipe for B-37	2 pc.	100235-0-00						
A-14	Oil Pad for Hole of B-55	1 pc.	108520-0-01						
A-16	Face Plate	1 pc.	100391-0-01						
A-19	Set Screw for A-20	1 pc.	100393-0-01						
A-20	Face Plate Thread Guide F	1 pc.	116005-0-01	100390-0-01					
A-21	Face Plate Thread Guide E	1 pc.	100392-0-01						
A-22	Set Screw for A-21	1 pc.	100393-0-01						
A-17	Set Screw for A-16	1 pc.	100287-0-04						
A-18	Set Screw for A16	1 pc.	100395-0-01						
A-23	Cover Plate for B-4	1 pc.	100241-0-01						
A-24	Set Screw for A-24	1 pc.	100242-0-04						
A-25	Set Screw for A-26	1 pc.	103980-0-01						
A-26	Arm Thread Guide B	1 pc.	100389-0-01						
A-27	Set Screw for A-28	1 pc.	100388-0-04						
A-28	Thread Retainer A	1 pc.	114931-0-01						
A-29	Set Screw for A-31	1 pc.	103950-0-02						
A-30	Set Screw for A-34	1 pc.	100402-0-02						
A-31	Upper Thread Tension Bracket	1 pc.	100397-0-01						
A-32	Thread Releasing Pin	1 pc.	100400-0-00						
A-33	Thread Take Up Spring	1 pc.	100399-0-01	180195-0-01					
A-34	Tension Stud	1 pc.	100398-0-01						
A-35	Tension Disc	2 pcs.	108721-0-01						
A-36	Tension Disc Washer	1 pc.	100134-0-01						
A-37	Tension Spring	1 pc.	100401-0-01						
A-38	Thread Tension Control Nut	1 pc.	100136-0-01						
A-39	Slide Plate	1 pc.	100268-0-01						
A-40	Slide Plate Spring	1 pc.	100269-0-01	118289-0-01					
A-41	Slide Plate Spring Screw	2 pcs.	100035-0-01						
A-42	Needle Plate Screw	2 pc.	100032-0-01						
A-43	Needle Plate B-18	1 pc.	100268-0-01						
A-44	Armbud	1 pc.	102575-0-01						
A-45	Oil Cap for B-73	1 pc.	140890-0-01						
A-46	Model Plate	1 pc.	143258-0-01						
A-47	Model Plate Pin	2 pc.	116231-0-01						

B760-4



Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.	Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.
B-1	Oil Felt for B-3	1 pco.	115812-0-02		B-42	Arm Pulley	1 pco.	10605-0-01	
B-2	Set Screw for B-3	1 #	100260-0-01		B-43	Cap Screw for B-30, B-42	1 #	104478-0-01	
B-3	Needle Bar Bushing Upper	1 #	100259-0-01	182060-0-01	B-44	Set Screw for B-42	2 pco.	100016-0-03	
B-4	Needle Bar	1 #	100258-0-01		B-45	Oil Seal Right for B-30	1 pco.	103738-0-01	
B-5	Needle Bar Bushing Lower	1 #	109206-0-01		B-46	Oil Seal for B-55	2 pco.	103796-0-01	
B-6	Set Screw for B-5	1 #	100260-0-01		B-47	Upper Gear Case	1 pco.	110349-0-00	
B-7	Needle Clamp	1 #	116951-0-01	180017-0-01	B-48	Grease Hole Cap B-47	1 #	100630-0-00	
B-8	Needle Clamp Screw	1 #	118521-0-01		B-49	Set Screw for B-47	1 #	100628-0-01	
B-9	Set Screw for B-10	1 #	100393-0-01		B-52	Oil Felt for B-53, B-59, B-67, B-73	4 pco.	100633-0-01	
B-10	Needle Bar Thread Guide G	1 #	112190-0-01		B-53	Vertical Shaft Upper Bushing	1 pco.	103558-0-00	
B-11	Needle DBX1	1 #	100265-0-14		B-54	Set Screw for B-53	1 #	100016-0-03	
B-12	Clamp Screw for B-13	1 #	140004-0-01		B-55	Vertical Shaft	1 #	103557-0-01	
B-13	Needle Bar connecting Stud	1 #	102632-0-01		B-56	Vertical Shaft Collar	1 #	100356-0-01	
B-14	Stud for Thread Take Up Supporter	1 #	104376-0-01	106121-0-01	B-57	Set Screw for B-56	2 pco.	101706-0-01	
B-15	Set Screw for B-14	1 #	100016-0-01		B-58	Set Screw for B-59	1 pco.	100016-0-03	
B-16	Thread Take Up	1 #	100271-0-01		B-59	Vertical Shaft Lower Bushing	1 #	100634-0-00	
B-20	Needle Bar Crank	1 #	100252-0-01		B-60	Vertical Shaft Lower Gear	1 #	117799-0-01	
B-21	Needle Bar Crank Rod	1 #	100600-0-01		B-61	Set Screw for B-60	1 #	100251-0-01	180145-0-01
B-22	Cap Screw for B-20	1 #	100253-0-01		B-65	Lower Shaft Gear	1 pco.	117001-0-01	
B-17	Thread Take Up Crank	1 #	142097-0-00		B-66	Set Screw for B-65	2 pco.	100251-0-01	
B-18	Take Up Crank Position Screw	1 #	104461-0-01		B-62	Oil Seal for B-71	1 #	103797-0-01	
B-19	Set Screw for B-17	2 pco.	100251-0-01		B-63	Lower Gear Case	1 #	110320-0-00	
B-23	Needle Bar Guide Slide Block	1 pco.	102630-0-01		B-64	Set Screw for B-63	1 #	100343-0-01	
B-24	Needle Bar Guide	1 #	102631-0-00		B-67	Lower Shaft Bushing Right	1 #	100638-0-00	
B-25	Set Screw for B-24	2 pco.	100137-0-01		B-68	Set Screw for B-67	1 pco.	100539-0-02	
B-26	Set Screw for B-27	1 pco.	100016-0-03		B-69	Set Screw for B-70	2 pco.	101706-0-01	
B-27	Upper Shaft Bearing Left	1 #	142102-0-00		B-70	Lower Shaft Collar	1 #	100356-0-01	
B-28	Wick 6x6 for B-27, B-32, B-41, B-53, B-59, B-67, B-73	7 pco.	108805-0-01		B-71	Lower Shaft	1 #	100351-0-01	
B-29	Oil Felt for B-27, B-41	2 #	100248-0-01		B-72	Set Screw for B-73	1 #	100539-0-02	
B-30	Upper Shaft	1 pco.	142101-0-01		B-73	Lower Shaft Bushing Left	1 #	100637-0-00	
B-31	Set Screw for B-32	1 #	100016-0-03		B-75	Rotary Hook Assembly	1 #	111274-0-01	
B-32	Upper Shaft Bearing Intermediate	1 #	100597-0-00		B-76	Set Screw for B-77	1 #	100368-0-02	
B-33	Oil Felt for B-32	1 #	100598-0-01		B-77	Bobbin Case Holder position Bracket	1 #	100367-0-01	
B-34	Upper Shaft Collar	1 #	104274-0-00		B-78	Bobbin	1 #	117132-0-01	
B-35	Set Screw for B-34	2 pco.	100251-0-01		B-79	Bobbin Case	1 pco.	100369-0-01	
B-36	Set Screw for B-37	2 #	100013-0-03		B-80	Set Screw for B-81	2 pco.	107428-0-01	
B-37	Feed & Feed Lifting Eccentric	1 pco.	100307-0-00		B-81	Crank Rod	1 pco.	100335-0-01	
B-38	Steeve for B-37	1 #	106424-0-04	180192-0-01	B-82	Taper Screw B-81	1 #	100310-0-01	
B-39	Set Screw for B-39	2 pco.	100251-0-01		B-83	Nut for B-82	1 #	104689-0-01	
B-38	Upper Shaft Gear	1 pco.	116998-0-01	180144-0-01	B-84	Taper Hinge Screw for B-86	1 #	100310-0-01	
B-50	Vertical Shaft Gear	1 #	117797-0-01		B-85	Nut for B-84	1 #	104689-0-01	
B-51	Set Screw for B-50	2 pco.	100251-0-01		B-86	Feed Forked Connecting	1 #	100309-0-01	
B-40	Set Screw for B-41	1 #	100062-0-04		B-88	Felt for B-87	1 #	106442-0-01	
B-41	Upper Shaft Bearing Right	1 #	103555-0-00		B-89	Felt Wire for B-87	1 #	106440-0-00	

B760-6



From the library of: Superior Sewing Machine & Supply LLC

Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.	Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.
C-1	Pressor Foot Control Screw	1 pco.	100279-0-01		C-46	Length Control Screw	1 pco.	100322-0 01	
C-2	Pressor Spring Washer	1 "	141099-0-01		C-47	Direction Control	1 "	100316-0-01	
C-3	Pressor Spring	1 "	117880-0-01		C-48	Stud Screw for C-47	1 "	100321-0 01	
C-4	Pressor Bar	1 "	103013-0-01		C-50	Clamp Screw for C-47	1 "	100320-0-02	
C-5	Pressor Bar Bushing	1 "	110340-0-01		C-51	Nut for C-52	2 pco.	100075-0-03	
C-6	Pressor Foot Set Screw	1 "	100287-0-04		C-52	Center Screw for C-55	2 "	100331-0-02	
C-7	Pressor Foot	1 "	113280-0-01		C-53	Feed Rock Shaft Arm	1 pco.	100324-0 02	
C-8	Stud Screw for C-9	1 "	109801-0-01		C-54	Clamp Screw for C-53	1 "	100086-0-03	
C-9	Pressor Lifter	1 "	100291-0-01		C-55	Feed Rock Shaft	1 "	100330-0 03	
C-10	Set Screw for C-8	1 "	100013-0-02		C-56	Set Screer for C-57	2 pco.	100080-0-03	
C-11	Pressor Bar Guide Bracket	1 "	100288-0-01		C-57	Feed dog	1 pco.	100330-0 01	100-334-00
C-12	Set Screw for C-11	1 "	100013-0-03		C-58	Feed Bar	1 "	100332-0 01	
C-13	Set Screw for C-14	1 "	100080-0-03		C-59	Center Screw for C-58	2 pco.	100333-0 01	
C-14	Pressor Bar Bracket Thread Guide for C-11	1 "	117178-0-01		C-60	Nut for C-59	2 "	100078-0 03	
C-15	Stud Screw for C-20	1 "	100294-0-01		C-61	Nut for C-62	2 "	100095-0-03	
C-16	Pressor Lifter Bracket	1 "	100290-0-01		C-62	Center Screw for C-65	2 "	100331-0-02	
C-17	Taper pin for C-18	1 "	100404-0-00		C-63	Feed Lifting Arm Assembly	1 pco.	100338-0 01	
C-18	Tension Release Crank	1 "	113547-0 01		C-64	Clamp Screw for C-63	1 "	100036-0-03	
C-19	Tension Release Crank Spring	1 "	100405-0-01		C-65	Feed Lifting Lock Shaft	1 "	100317-0 03	
C-20	Pressor Bar Lifting Connector	1 "	100293-0-01		C-67	Direction Control Spring	1 "	117817-0 01	
C-21	Knee Lifter Pin	1 "	100297-0-01						
C-22	Set Screw for C-21	1 "	100013-0-03						
C-23	Knee Lifter Lever	1 "	100295-0 01						
C-24	Hinge Screw for C-23	1 "	102921-0-02						
C-25	Stud Screw for C-26	1 "	100299-0 01						
C-26	Knee Lifter Joint	1 "	100298-0 01						
C-27	Nut for C-28	1 "	110161-0 03						
C-28	Knee Lifter Connecting Rod	1 pco.	100300-0 01						
C-29	Hinge Pin for C-30	1 "	118550-0-00						
C-30	Knee Lifter Crank beneath Rod	1 "	117924-0-01						
C-31	Spring for C-30	1 "	100304-0-01						
C-32	Set Screw for C-33	2 pco.	100306-0 03						
C-33	Bracket for C-30	1 pco.	100305-0 01						
C-34	Set Screw for C-41	1 "	102627-0-01						
C-35	Feed Regulator	1 "	100313-0 01						
C-37	Stud Screw for Feed Regulator	1 "	141098-0-01						
C-38	Taper Hinge Screw	1 "	100310-0-01						
C-39	Feed Regulator Link	1 "	100311-0-00						
C-40	Nut for C-38	1 "	104689-0 01						
C-41	Taper Hinge for C-35	1 "	100312-0 01						
C-42	Spring for C-43	1 "	100328-0-01						
C-43	Notch Pin for C-44	1 "	100327-0-01						
C-44	Length Control	1 "	113353-0 01						
C-45	Set Screw for C-44	1 "	100326-0-03						