
PFAFF[®]

293



Unterklassen-Ausstattung

Subclass parts

Composition des sous-classes

Composición de las subclases










Unterklassen-Ausstattung
Subclass organizations

Equipement des sous-classes
Dotación de las subclases

Unterklasse Subclass Sous-classe Subclase	Ausführung Model Version Tipo de máquina	Nadelstange Needle bar Barre à aiguille Barra de aguja	Stoffschieber ⁴ Feed dog Griffe Transportador interior	Stichplatte ⁴ Needle plate Plaque à aiguille Placa de aguja	Nähfuß ⁴ Presser foot Pied presseur Pie prensateelas	Fingerschutz Finger guard Protège-dedits Salvadedos
-750/01-4/01	BN	91-009 678-91	91-046 440-04	91-045 600-04	91-141 232-13	91-012 658-91
-750/01-4/01-900/56	BN	91-009 678-91	91-059 186-04	91-158 225-04	91-141 232-13	91-012 658-91
-944/01	BN	91-009 678-91	91-046 440-04	91-045 600-04	91-051 255-93	91-157 813-91
-944/01-900/56	BN	91-009 678-91	91-059 186-04	91-158 225-04	91-051 255-93	91-157 813-91

⁴ = Ausführung angeben
= indicate model
= Preciser la version
= Indíquese el tipo de máquina

Unterklassen-Übersicht/ Table of subclasses/ Table des sous-classes/ Tabla de subclases

91-009 678-91  91-709 310-01 91-700 336-15 91-700 226-15 91-005 024-05	91-046 440-04 ⁴  -750/01-4/01 -944/01	91-059 186-04 ⁴  -750/01-4/01-900/56 -944/01-900/56	91-045 600-04 ⁴  -750/01-4/01 -944/01
-750/01-4/01 -750/01-4/01-900/56 -944/01 -944/01-900/56	91-158 225-04 ⁴  -750/01-4/01-900/56 -944/01-900/56	91-051 255-93 ⁴  -944/01 -944/01-900/56	91-141 232-13  -750/01-4/01 -750/01-4/01-900/56
	91-012 658-91  -750/01-4/01 -750/01-4/01-900/56	11-108 222-15  11-108 222-15 11-108 171-15 11-108 171-15 91-157 885-15 91-157 814-91 91-157 813-91 -944/01 -944/01-900/56	

Pfaff, D 6750 Kaiserslautern, Postfach 3020/3040, Telefon (0631) 200-0, Telex: 45753, Telefax (0631) 17202