

# PFAFF


441-R -705/03  
-755/03

Unterklassen-Ausstattung

Subclass parts

Composition des sous-classes

Composición de las subclases
















**Table des sous-classes**  
**Tabla de subclases** PFAFF 441-R-705/03














Unterklasse Subclass Sous-classe Subclase	<b>-705/03</b>				
Ausführung Model Version Tipo de máquina	AN 2,5	BN 2,5	A	B	BC
Nadelstange Needle bar Barre à aiguille Barra de aguja	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91
Stoffschieber [4] Feed dog Griffe Transportador inferior	91-119 544-05	91-119 546-05	91-119 544-05	91-119 546-05	91-119 546-05
Stichplatte [4] Needle plate Plaque à aiguille Placa de aguja	91-058 517-04	91-058 517-04	91-058 518-04	91-058 518-04	91-058 519-04
Nähfuß [4] Presser foot Pied presseur Pie prensatelas	91-055 874-93	91-055 874-93	91-055 874-93	91-055 874-93	91-055 874-93
Fingerschutz Finger guard Protège-doigts Salvadedos	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91
Unterklasse Subclass Sous-classe Subclase	<b>-705/03-900/61</b>				
Ausführung Model Version Tipo de máquina	AN 2,5	BN 2,5	A	B	BC
Nadelstange Needle bar Barre à aiguille Barra de aguja	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91
Stoffschieber [4] Feed dog Griffe Transportador inferior	91-119 544-05	91-119 546-05	91-119 544-05	91-119 546-05	91-119 546-05
Stichplatte [4] Needle plate Plaque à aiguille Placa de aguja	91-158 808-04	91-158 808-04	91-158 808-04	91-158 808-04	91-158 809-04
Nähfuß [4] Presser foot Pied presseur Pie prensatelas	91-055 874-93	91-055 874-93	91-055 874-93	91-055 874-93	91-055 874-93
Fingerschutz Finger guard Protège-doigts Salvadedos	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91

Table of subclasses  
 Table des sous-classes  
 Tabla de subclases

PFAFF 441-R-755/03

Unterklasse Subclass Sous-classe Subclase	<b>-755/03</b>				
Ausführung Model Version Tipo de máquina	AN 2,5	BN 2,5	A	B	BC
Nadelstange Needle bar Barre à aiguille Barra de aguja	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91
Stoffschieber  Feed dog Griffe Transportador inferior	91-119 544-05	91-119 546-05	91-119 544-05	91-119 546-05	91-119 546-05
Stichplatte  Needle plate Plaque à aiguille Placa de aguja	91-058 517-04	91-058 517-04	91-058 518-04	91-058 518-04	91-058 519-04
Nähfuß  Presser foot Pied presseur Pie prensatelas	91-119 787-93	91-119 787-93	91-119 787-93	91-119 787-93	91-119 787-93
Fingerschutz Finger guard Protège-doigts Salvadedos	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91
Unterklasse Subclass Sous-classe Subclase	<b>-755/03-900/61</b>				
Ausführung Model Version Tipo de máquina	AN 2,5	BN 2,5	A	B	BC
Nadelstange Needle bar Barre à aiguille Barra de aguja	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91	91-175 110-91
Stoffschieber  Feed dog Griffe Transportador inferior	91-119 544-05	91-119 546-05	91-119 544-05	91-119 546-05	91-119 546-05
Stichplatte  Needle plate Plaque à aiguille Placa de aguja	91-158 808-04	91-158 808-04	91-158 808-04	91-158 808-04	91-158 809-04
Nähfuß  Presser foot Pied presseur Pie prensatelas	91-119 787-93	91-119 787-93	91-119 787-93	91-119 787-93	91-119 787-93
Fingerschutz Finger guard Protège-doigts Salvadedos	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91	91-053 938-91

 siehe Erläuterungen Register    
 see explanations in section    
 voir légende registre  

<p>91-175 110-91</p>  <p>91-175 096-05</p> <p>91-118 196-12</p>  <p>11-174 173-15</p>  <p>91-175 097-05</p> <p>11-174 089-15</p> <p>91-175 098-05</p>	<p>91-119 544-05</p>  <p>-705/03 AN2,5; A          -705/03-900/61 AN2,5; A          -755/03 AN2,5; A          -755/03-900/61 AN2,5; A</p>	<p>91-119 546-05</p>  <p>-705/03 BN2,5; B; B/C          -705/03-900/61 BN2,5; B; B/C          -755/03 BN2,5; B; B/C          -755/03-900/61 BN2,5; B; B/C</p>	<p>91-058 517-04 [A]</p>  <p>-705/03 AN2,5; BN2,5          -755/03 AN2,5; BN2,5</p>
<p>91-158 808-04 [A]</p>  <p>-705/03-900/61 A; B; AN2,5; BN2,5          -755/03-900/61 A; B; AN2,5; BN2,5</p>	<p>91-158 809-04 [A]</p>  <p>-705/03-900/61 B/C          -755/03-900/61 B/C</p>	<p>91-058 518-04 [A]</p>  <p>-705/03 A; B          -755/03 A; B</p>	<p>91-058 519-04 [A]</p>  <p>-705/03 B/C          -755/03 B/C</p>
<p>91-053 938-91</p>  <p>-705/03          -705/03-900/61          -755/03          -755/03-900/61</p>	<p>11-173 174-15</p>  <p>91-055 874-93 [A]</p> <p>-705/03          -705/03-900/61</p>	<p>91-119 787-93 [A]</p>  <p>91-119 469-05</p> <p>13-033 145-05</p> <p>12-664 290-45</p> <p>99-133 116-01</p> <p>99-133 116-01</p> <p>12-518 210-45</p> <p>91-119 807-15</p> <p>11-178 172-15</p> <p>91-119 953-15</p> <p>11-210 043-15</p> <p>91-119 491-05</p> <p>-755/03          -755/03-900/61</p>	